


ACCENTRA

ASSA ABLOY

nexTouch®
Exit Trim Lock
For Arrow S1250
Exit Device


NOTES:

1. This door marker is for Arrow S1250 Exit Device.
2. Apply to outside face of door using knockout windows to locate centerlines.
3. If door thickness is other than 1-3/4", or backset is other than 2-3/4", do not place on edge. Find backset by measuring from the centerline of beveled edge.
4. Dimensions given in inches.



CAUTION
If printed from website
Print 1:1 Scale
Measure both 3" lines to check scale

OUTSIDE OF DOOR



**DRAW CENTERLINE ON 2-3/4" (70 mm) BACKSET
(MEASURED FROM CENTERLINE OF DOOR EDGE BEVEL)
SEE NOTE 3.**

